

**MatrixPRO-II**  
**HD/3G SDI series**  
**User manual**

Rev. 00

- **Manual #: 26-0903001-00**
- **Revision: 00**



## Copyright

© Barco. May 6, 2010

All rights reserved. No part of this document may be copied, reproduced or translated. It shall not otherwise be recorded, transmitted or stored in a retrieval system without the prior written consent of Barco.

## Notice

Barco provides this manual "as is" without warranty of any kind, either expressed or implied, including but not limited to the implied warranties or merchantability and fitness for a particular purpose. Barco may make improvements and/or changes to the product(s) and/or the program(s) described in this publication at any time without notice.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information in this publication; these changes are incorporated in new editions of this publication.

## Federal Communications (FCC) Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the user will be responsible for correcting any interference.

## Guarantee and Compensation

Barco provides a guarantee relating to perfect manufacturing as part of the legally stipulated terms of guarantee. On receipt, the purchaser must immediately inspect all delivered goods for damage incurred during transport, as well as for material and manufacturing faults. Barco must be informed immediately in writing of any complaints.

The period of guarantee begins on the date of transfer of risks, in the case of special systems and software on the date of commissioning, at latest 30 days after the transfer of risks. In the event of justified notice of complaint, Barco can repair the fault or provide a replacement at its own discretion within an appropriate period. If this measure proves to be impossible or unsuccessful, the purchaser can demand a reduction in the purchase price or cancellation of the contract. All other claims, in particular those relating to compensation for direct or indirect damage, and also damage attributed to the operation of software as well as to other services provided by Barco, being a component of the system or independent service, will be deemed invalid provided the damage is not proven to be attributed to the

absence of properties guaranteed in writing or due to the intent or gross negligence or part of Barco.

If the purchaser or a third party carries out modifications or repairs on goods delivered by Barco, or if the goods are handled incorrectly, in particular if the systems are commissioned operated incorrectly or if, after the transfer of risks, the goods are subject to influences not agreed upon in the contract, all guarantee claims of the purchaser will be rendered invalid. Not included in the guarantee coverage are system failures which are attributed to programs or special electronic circuitry provided by the purchaser, e.g. interfaces. Normal wear as well as normal maintenance are not subject to the guarantee provided by Barco either.

The environmental conditions as well as the servicing and maintenance regulations specified in this manual must be complied with by the customer.

## Trademarks

Brand and product names mentioned in this manual may be trademarks, registered trademarks or copyrights of their respective holders. All brand and product names mentioned in this manual serve as comments or examples and are not to be understood as advertising for the products or their manufactures.

## Company Address



**Barco, Inc.**  
11101 Trade Center Drive  
Rancho Cordova,  
California 95670 USA  
Phone: (916) 859-2500  
Fax: (916) 859-2515

**Barco N.V.**  
Noordlaan 5 8520  
Kuurne  
BELGIUM  
Phone: +32 56.36.82.11  
Fax: +32 56.35.16.51

Website: [www.barco.com](http://www.barco.com)

### Technical Support

**Customer Service Portal** — [www.barco.com/esupport](http://www.barco.com/esupport)  
**(866) 374-7878** — Events (24/7)  
**(866) 469-8036** — Digital Cinema (24/7)

## Operators Safety Summary

The general safety information in this summary is for operating personnel.

### Do not remove panels or covers

There are no user-serviceable parts within the unit. Removal of the top cover will expose dangerous voltages. To avoid personal injury, do not remove the top cover. Do not operate the unit without the cover installed.

### Power Source

This product is intended to operate from a power source that will not apply more than 230 volts rms between the supply conductors or between both supply conductor and ground. A protective ground connection by way of grounding conductor in the power cord is essential for safe operation.

### Grounding the Product

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting to the product input or output terminals. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.

### Use of the Power Cord

Use only the power cord and connector specified for your product. Use only a power cord that is in good condition. Refer cord and connector changes to qualified service personnel.

### Use of the Proper Fuse

To avoid fire hazard, use only the fuse having identical type, voltage rating, and current rating characteristics. Refer fuse replacement to qualified service personnel.

### Do not Operate in Explosive Atmospheres

To avoid explosion, do not operate this product in an explosive atmosphere.

## Terms in This Manual and Equipment Marking

### Warning



Highlights an operating procedure, practice, condition, statement, etc., which, if not strictly observed, could result in injury to or death of personnel.

### NOTE

Highlights an essential operating procedure, condition,



### Caution

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



### AVETISSEMENT!

Le point d'exclamation dans un triangle équilatéral signale à alerter l'utilisateur qu'il y a des instructions d'opération et d'entretien très importantes dans la littérature qui accompagne l'appareil.



### VORSICHT

Ein Ausrufungszeichen innerhalb eines gleichwinkligen Dreiecks dient dazu, den Benutzer auf wichtige Bedienungs- und Wartungsanweisungen in der dem Gerät beiliegenden Literatur aufmerksam zu machen.

## Change History

| <b>Rev</b> | <b>Date</b> | <b>ECP #</b> | <b>Description</b> | <b>Approved By</b> |
|------------|-------------|--------------|--------------------|--------------------|
| 00.00      | 5/20/10     | 578607       | Initial Release    | R. Pellicano       |
|            |             |              |                    |                    |
|            |             |              |                    |                    |

## Contents

|   |    |
|---|----|
| 1.1 Product versions .....                                      | 9  |
| 2 Specifications .....  | 10 |
| 2.1 Mechanics.....  | 10 |
| 2.1.1 Weight and power consumption .....                        | 10 |
| 2.2 Power Supply.....   | 10 |
| 2.3 Control.....  | 10 |
| 2.4 Video specifications.....                                   | 11 |
| 2.5 Connection details .....                                    | 12 |
| 2.5.1 Power Supply pinout.....                                  | 12 |
| 3 Configuration.....  | 13 |
| 3.1 SW1 – SW4: Address/Level Not Used .....                     | 13 |
| 3.2 SW5-SW6: Router mode .....                                  | 13 |
| 3.2.1 Router mode on NxN square routers.....                    | 13 |
| 3.3 SW7: Power alarm.....                                       | 17 |
| 3.4 SW8: Power-up mode.....                                     | 17 |
| 3.5 Switching time.....   | 18 |
| 3.6 Configuring protocol options.....                           | 18 |
| 4 LED status indication .....                                   | 19 |
| 4.1 Start-up.....   | 19 |
| 4.2 Alarm states .....  | 19 |
| 4.3 Ethernet states.....  | 19 |
| 5 Router communication .....                                    | 20 |
| 5.1 Serial connection .....                                     | 20 |
| 5.1.1 Maximum cable length (RS-232).....                        | 20 |
| 5.2 Ethernet connection .....                                   | 21 |
| 6 Control Panel operation.....                                  | 22 |
| 6.1 Button description .....                                    | 22 |
| Environmental Specifications.....                               | 24 |
| Appendix A Materials declaration and recycling information..... | 25 |
| A.1 Materials declaration.....                                  | 25 |
| A.2 Recycling information .....                                 | 26 |



## Product overview

This User Manual presents the features, installation and operation procedures of (3G/HD/SD-SDI) routers of the Barco MatrixPRO-II series.

- Router models available: 8x8, 16x61 and 32x32
- TCP/IP and RS-232
- Programmable multi- single- and dual bus control panels
- Ultra Slim frame depth
- Low Power, high reliability design
- Redundant power supply system with front indicators
- Future proof and flexible product range

Barco's MatrixPRO-II 3G/HS/SD-SDI series is ideal for general events, fixed installations, on-air routing, mobile outside broadcast applications and sophisticated A/V applications.

### 1.1 Product versions

The following versions of the Barco MatrixPRO-II 3G/HD/SD-SDI Routers are available:

#### 1RU, Depth 5cm

|                                    |  |
|------------------------------------|--|
| R9004661                           | 8x8 HD/3G Digital Video Router<br>Multirate: 270Mbps-2.97Gbps<br>Router partitioning.<br>Reclocking.   |
| R9004660                           | 16x16 HD/3G Digital Video Router<br>Multirate: 270Mbps-2.97Gbps<br>Router partitioning.<br>Reclocking. |
| <b>2RU, depth 5cm:</b><br>R9004662 | 32x32 HD/3G Digital Video Router<br>Multirate: 270Mbps-2.97Gbps<br>Router partitioning.<br>Reclocking. |

## 2 Specifications

### 2.1 Mechanics

Dimensions:                               -       HxWxD = 44x483x50mm, (19", 1RU);  
   -       HxWxD = 88x483x50mm, (19", 2RU);  
 Safety/Emission Standards:       Compliant with CE EN55103-1 and 2.

#### 2.1.1 Weight and power consumption

| Device   | Weight  | Current, +15V  | Current, -15V | Power |
|----------|---------|----------------|---------------|-------|
| R9004661 | 1.3 kg  | 900 mA         | 2 mA          | 14 W  |
| R9004660 | 1.4 kg  | 1273 mA        | 4 mA          | 19 W  |
| R9004662 | 2.2 kg  | 1302 mA        | 1035 mA       | 35 W  |
| R9871081 | 0.35 kg | N/A (AC Mains) |               |       |

### 2.2 Power Supply

SL-PWR-40                               40W Power Supply Unit  
 AC Supply voltage range:       100-240VAC, 50-60Hz,  
   Max 1.6A  
 AC Mains connector:               IEC 320.  
 DC output:                               +15V, max. 2.2A  
   -15V, max 1.35A  
   Maximum 43W  
 DC connector:                         DB9, female.  
 Status monitoring:                 Via LED in front of the router/CP.  
 Safety standards:                   Compliant with CE EN60950, UL-1950/CSA22.2.

### 2.3 Control

| Function        | Description   | Connector     |
|-----------------|---|---------------|
| Serial Port     | RS-232  | 1xDB9, female |
| NCB             | N/A   | 2x RJ45       |
| Ethernet port:  | 10/100BaseT Ethernet bus for external router control.   | 1x RJ45       |
| Synchronization | <ul style="list-style-type: none"> <li>o Analog Black &amp; Burst, looped. Both PAL and NTSC supported.</li> </ul> Tri-Level, Looped. For HD signal formats only. | 1xBNC         |

## 2.4 Video specifications

### Supported formats:

- Broadcast:
- 270Mbps – 2.97Gbps;
  - DVB-ASI, SMPTE 259M, SMPTE 292M, SMPTE 424M;
  - 2K, 2048x1556/23.98 and 24.

### Electrical signal inputs:

- Standard: SMPTE 259M / SMPTE 292M / SMPTE 424M.  
 Data rate: 270Mbps – 1.485Gbps / 2.97Gbps.  
 Connector: 75 ohm BNC female.  
 Impedance: 75 ohm nominal.  
 Return loss:
  - > 15dB (5MHz-1.485Ghz);
  - > 10dB (1.5GHz – 3GHz).
 Cable equalization,
  - Automatic up to 70m @ 2.97Gbps, typical Belden 1694A;
  - Automatic up to 100m @ 1.485Gbps, typical Belden 1694A.
  - Automatic up to 300m @ 270Mbps, typical Belden 8281.

### Electrical signal outputs:

- Connector: 75 ohm BNC female.  
 Impedance: 75 ohm nominal.  
 Return loss:
  - > 15dB (5MHz-1.485Ghz);
  - > 10dB (1.5GHz – 3GHz).
 Signal level: 800mVp-p ±10%.  
 Rise/fall time: 20% - 80%
  - SD limit: 0.4ns – 1.5ns, < 0.5ns rise/fall variation;
  - HD limit: < 270ps, < 100ps rise/fall variation;
  - 3G-HD limit: < 135ps, < 50ps rise/fall variation;
 Amplitude overshoot: < 10%.  
 Signal polarity: Non-inverting electrical with respect to inputs.  
**Signal transition:**  
 Timing jitter:
  - SD: < 0.2 UI
  - 3G-HD / HD: < 1 UI.
 Alignment jitter:
  - SD: < 0.2 UI
  - 3G-HD / HD: < 0.2 UI.

### Reference inputs:

- Number of inputs: 1  
 Connector: 75 ohm BNC female, loop-thru.  
 Return loss: >40dB (100 kHz – 5 MHz);  
 >35dB (5-10 MHz).  
 Signal format: NTSC or PAL Black&Burst or HD Tri-Level according to SMPTE 274M, SMPTE 276M.  
 Signal level: Nominal 1.0Vp-p.

|                    |  |
|--------------------|--|
| Field selectivity: | Field 1.   |
| Timing range:      | <ul style="list-style-type: none"> <li>- SD, PAL: within clock-intervals (27MHz) 565 – 835 line 6</li> <li>- SD, NTSC: within clock-intervals (27MHz) 565 – 835 line 10.</li> <li>- HD Tri-Level: 1280x720: within clock-intervals (148.5MHz) 455 – 780 line 7</li> <li>- HD Tri-Level: 1920x1080: within clock-intervals (148.5MHz) 625 – 1070 line 7.</li> </ul> |

## 2.5 Connection details

The MatrixPRO-II routers have the following service connections on the rear of each product:

|                       |  |
|-----------------------|--|
| <b>SYNC:</b>          | Synchronization signal (in). Black burst/composite/tri-level sync reference input with passive loop-through for vertical interval switching. |
| <b>LOOP:</b>          | Synchronization signal (out). Loop-through of SYNC input.  |
| <b>NCB IN/OUT</b>     | N/A.   |
| <b>ETHERNET:</b>      | 10/100Base-T Ethernet bus for external router control.   |
| <b>RS 232:</b>        | RS-232 for external control protocols.   |
| <b>POWER A:</b>       | ±15VDC power connector.  |
| <b>POWER B:</b>       | ±15VDC power connector, redundant supply.  |
| <b>CONFIGURATION:</b> | Configurations switch. See Chapter 3 for further descriptions.   |

### 2.5.1 Power Supply pinout

The DB9 power pinout for MatrixPRO-II routers is as follows;

| Pin # | Description   |
|-------|---------------|
| 1     | GND           |
| 2     | Not connected |
| 3     | Not connected |
| 4     | +15VDC        |
| 5     | Not connected |
| 6     | Not connected |
| 7     | Not connected |
| 8     | -15VDC        |
| 9     | Not connected |

### 3 Configuration

This chapter provides an overview of the configuration options that are available on the Barco MatrixPRO-II 3G/HD/SD-SDI Routers.

#### 3.1 SW1 – SW4: Address/Level Not Used

#### 3.2 SW5-SW6: Router mode

##### 3.2.1 Router mode on NxN square routers

The nxn square Barco MatrixPRO-II A/V router allows switching in different modes:

| Router layers | 8x8 router | 16x16 router | 32x32 router |
|---------------|------------|--------------|--------------|
| 1 layer       | 8x8        | 16x16        | 32x32        |
| 2 layers      | 4x4        | 8x8          | 16x16        |
| 3 layers      | N.A.       | 5x5          | 10x10        |
| 4 layers      | 2x2        | 4x4          | 8x8          |

Switches 5 - 6 on the configuration switch set the router's mode. The Router Management System software must be configured according to the mode chosen on the router.

The modes can be switched according to the following pattern:

| SW 5      | SW 6      | Router mode     |
|-----------|-----------|-----------------|
| OFF       | OFF       | 1 router layer  |
| OFF       | <b>ON</b> | 2 router layers |
| <b>ON</b> | OFF       | 3 router layers |
| <b>ON</b> | <b>ON</b> | 4 router layers |

Default mode is 1 router layer.

Based on the configuration above, the I/O is connected to the router according to the following scheme, where the physical limitations depend on the type of router that is purchased (8x8, 16x16, 32x32):

- **1 layer:**  
I/O is connected according to information on the rear of the router.

- 2 layers, based on an 8x8 router:

| Layer 1 | Input | Layer 1 | Output |
|---------|-------|---------|--------|
| 1       | 1     | 1       | 1      |
| 2       | 2     | 2       | 2      |
| 3       | 3     | 3       | 3      |
| 4       | 4     | 4       | 4      |
| Layer 2 | Input | Layer 2 | Output |
| 1       | 5     | 1       | 5      |
| 2       | 6     | 2       | 6      |
| 3       | 7     | 3       | 7      |
| 4       | 8     | 4       | 8      |

- 2 layers, based on a 16x16 router:

| Layer 1 | Input | Layer 1 | Output |
|---------|-------|---------|--------|
| 1       | 1     | 1       | 1      |
| 2       | 2     | 2       | 2      |
| 3       | 3     | 3       | 3      |
| 4       | 4     | 4       | 4      |
| ...     | ...   | ...     | ...    |
| 8       | 8     | 8       | 8      |
| Layer 2 | Input | Layer 2 | Output |
| 1       | 9     | 1       | 9      |
| 2       | 10    | 2       | 10     |
| 3       | 11    | 3       | 11     |
| 4       | 12    | 4       | 12     |
| ...     | ...   | ...     | ...    |
| 8       | 16    | 8       | 16     |

- 2 layers, based on a 32x32 router:

| Layer 1 | Input | Layer 1 | Output |
|---------|-------|---------|--------|
| 1       | 1     | 1       | 1      |
| 2       | 2     | 2       | 2      |
| 3       | 3     | 3       | 3      |
| 4       | 4     | 4       | 4      |
| ...     | ...   | ...     | ...    |
| 16      | 16    | 16      | 16     |
| Layer 2 | Input | Layer 2 | Output |
| 1       | 17    | 1       | 17     |
| 2       | 18    | 2       | 18     |
| 3       | 19    | 3       | 19     |
| 4       | 20    | 4       | 20     |
| ...     | ...   | ...     | ...    |
| 16      | 32    | 16      | 32     |

– **3 layers, based on a 16x16 router:**

| <b>Layer 1</b> | <b>Input</b> | <b>Layer 1</b> | <b>Output</b> |
|----------------|--------------|----------------|---------------|
| 1              | 1            | 1              | 1             |
| 2              | 2            | 2              | 2             |
| 3              | 3            | 3              | 3             |
| 4              | 4            | 4              | 4             |
| 5              | 5            | 5              | 5             |
| <b>Layer 2</b> | <b>Input</b> | <b>Layer 2</b> | <b>Output</b> |
| 1              | 6            | 1              | 6             |
| 2              | 7            | 2              | 7             |
| 3              | 8            | 3              | 8             |
| 4              | 9            | 4              | 9             |
| 5              | 10           | 5              | 10            |
| <b>Layer 3</b> | <b>Input</b> | <b>Layer 3</b> | <b>Output</b> |
| 1              | 11           | 1              | 11            |
| 2              | 12           | 2              | 12            |
| 3              | 13           | 3              | 13            |
| 4              | 14           | 4              | 14            |
| 5              | 15           | 5              | 15            |

In-/Output 16 is not in use in this router setup (3 router layers, based on a 16x16 router).

– **3 layers, based on a 32x32 router:**

| <b>Layer 1</b> | <b>Input</b> | <b>Layer 1</b> | <b>Output</b> |
|----------------|--------------|----------------|---------------|
| 1              | 1            | 1              | 1             |
| 2              | 2            | 2              | 2             |
| 3              | 3            | 3              | 3             |
| ...            | ...          | ...            | ...           |
| 10             | 10           | 10             | 10            |
| <b>Layer 2</b> | <b>Input</b> | <b>Layer 2</b> | <b>Output</b> |
| 1              | 11           | 1              | 11            |
| 2              | 12           | 2              | 12            |
| 3              | 13           | 3              | 13            |
| ...            | ...          | ...            | ...           |
| 10             | 20           | 10             | 20            |
| <b>Layer 3</b> | <b>Input</b> | <b>Layer 3</b> | <b>Output</b> |
| 1              | 21           | 1              | 21            |
| 2              | 22           | 2              | 22            |
| 3              | 23           | 3              | 23            |
| ...            | ...          | ...            | ...           |
| 10             | 30           | 10             | 30            |

In-/Outputs 31 and 32 are not in use in this router setup (3 router layers, based on a 32x32 router).

- **4 layers, based on an 8x8 router:**

| Layer 1 | Input | Layer 1 | Output |
|---------|-------|---------|--------|
| 1       | 1     | 1       | 1      |
| 2       | 2     | 2       | 2      |
| Layer 2 | Input | Layer 2 | Output |
| 1       | 3     | 1       | 3      |
| 2       | 4     | 2       | 4      |
| Layer 3 | Input | Layer 3 | Output |
| 1       | 5     | 1       | 5      |
| 2       | 6     | 2       | 6      |
| Layer 4 | Input | Layer 4 | Output |
| 1       | 7     | 1       | 7      |
| 2       | 8     | 2       | 8      |

- **4 layers, based on a 16x16 router:**

| Layer 1 | Input | Layer 1 | Output |
|---------|-------|---------|--------|
| 1       | 1     | 1       | 1      |
| 2       | 2     | 2       | 2      |
| 3       | 3     | 3       | 3      |
| 4       | 4     | 4       | 4      |
| Layer 2 | Input | Layer 2 | Output |
| 1       | 5     | 1       | 5      |
| 2       | 6     | 2       | 6      |
| 3       | 7     | 3       | 7      |
| 4       | 8     | 4       | 8      |
| Layer 3 | Input | Layer 3 | Output |
| 1       | 9     | 1       | 9      |
| 2       | 10    | 2       | 10     |
| 3       | 11    | 3       | 11     |
| 4       | 12    | 4       | 12     |
| Layer 4 | Input | Layer 4 | Output |
| 1       | 13    | 1       | 13     |
| 2       | 14    | 2       | 14     |
| 3       | 15    | 3       | 15     |
| 4       | 16    | 4       | 16     |

- **4 layers, based on a 32x32 router:**

| Layer 1 | Input | Layer 1 | Output |
|---------|-------|---------|--------|
| 1       | 1     | 1       | 1      |
| 2       | 2     | 2       | 2      |
| ...     | ...   | ...     | ...    |
| 8       | 8     | 8       | 8      |



| <b>Layer 2</b> | <b>Input</b> | <b>Layer 2</b> | <b>Output</b> |
|----------------|--------------|----------------|---------------|
| 1              | 9            | 1              | 9             |
| 2              | 10           | 2              | 10            |
| ...            | ...          | ...            | ...           |
| 8              | 16           | 8              | 16            |
| <b>Layer 3</b> | <b>Input</b> | <b>Layer 3</b> | <b>Output</b> |
| 1              | 17           | 1              | 17            |
| 2              | 18           | 2              | 18            |
| ...            | ...          | ...            | ...           |
| 8              | 24           | 8              | 24            |
| <b>Layer 4</b> | <b>Input</b> | <b>Layer 4</b> | <b>Output</b> |
| 1              | 25           | 1              | 25            |
| 2              | 26           | 2              | 26            |
| ...            | ...          | ...            | ...           |
| 8              | 32           | 8              | 32            |

### 3.3 SW7: Power alarm

The power alarm can be switched according to the following pattern:

| <b>SW 7</b> | <b>Power alarm</b>   |
|-------------|----------------------|
| OFF         | Disables Power Alarm |
| <b>ON</b>   | Enables Power Alarm  |

Default setting is Power Alarm disabled.

Changing this from default setting should only be done when using two (redundant) power supplies.

### 3.4 SW8: Power-up mode

Switch 8 on the configuration switch defines the power up mode on NxN square routers. The MatrixPRO-II router provides two modes for powering up the system.

The power up options can be switched according to the following pattern:

| <b>SW 8</b> | <b>Power Up mode</b>  |
|-------------|---|
| OFF         | Switches all outputs according to the buffered information in the routers processor system. |
| <b>ON</b>   | Switches all outputs to input 1.  |

Default setting switches all outputs according to the buffered information in the routers processor system.

### 3.5 Switching time

Switching is performed according to the detected sync reference signal. Switching time is determined by the synchronization signal that feeds the router. This is useful when the video signal has the same format as the synchronization signal. Supported formats are: PAL, NTSC, 750/50p, 750/60p, 1125/50i and 1125/60i.

### 3.6 Configuring protocol options

#### **TCP/IP**

This is the default option for the *Barco MatrixPRO-II HD/3G SDI routers*. *Selecting this protocol* disables the RS-232 port of that device.

#### **RS232**

The serial protocol can be selected from the configurator software. *Selecting the RS232 protocol* disables the Ethernet port of that device.

## 4 LED status indication

### 4.1 Start-up

The LED located at the front of the router indicates the status of the router. At start-up, the LED will alternate between red (R) and green (G) every 500ms for about two seconds. After the start-up sequence the LED will indicate the Alarm state of the router.

There are two LEDs located at the Ethernet bus. At start-up the boot loader is searching for update commands on the serial port for about two seconds. During this sequence both Ethernet LEDs will be blinking. After the start-up sequence the LEDs will indicate the Ethernet state.

### 4.2 Alarm states

The LED can either be red (R), green (G), yellow (Y) or have no light (N).

The LED state is here described with twenty letters, each representing 100ms, which totals to an alarm sequence of two seconds. The X indicates that the LED keeps the color it has the moment the alarm sequence begins (green, yellow or no light).

| Description             | LED state               | Alarm  | Comment  |
|-------------------------|-------------------------|--|--|
| Continuous green light  | GGGGG GGGGG GGGGG GGGGG | No alarm. Status is OK.                        |  |
| Continuous yellow light | YYYYY YYYYY YYYYY YYYYY | Unable to connect to controller over Ethernet. | This alarm will be overwritten by other alarms |
| Long red blinks         | RRRRR NNNNN RRRRR NNNNN | Power is too low.                              |  |
| One short red blink     | RXXXX XXXXX XXXXX XXXXX | Power A failed                                 | Only active if power alarm dip is set.         |
| Two short red blinks    | XXXXX XXXXX RXRXX XXXXX | Power B failed                                 | Only active if power alarm dip is set.         |

### 4.3 Ethernet states

The LEDs that are located at the Ethernet bus will after the Start-up sequence indicate the Ethernet states:

|        | On         | Off / Blinking                  |
|--------|------------|---------------------------------|
| Green  | Valid link | No link                         |
| Yellow | No data    | Data is transmitted or received |

## 5 Router communication

You gain access to router for communication purposes by connecting either the router's serial port to your computer or by using an Ethernet connection.

Do not use both the router's Ethernet port and RS-232 serial port at the same time. Doing so may cause loss of important communication and control data.

### 5.1 Serial connection

Connection can be made through the serial port(s) of the router;

The communication parameters are configurable. Please refer to the protocol documentation of the appropriate communication/control protocol.

Example: The protocol parameters are as follows:

- Bit rate 19200 bit/s
- Data bits 8 bits
- Stop bits 1
- Parity: No parity

The DB9 female connector for the serial port(s) of the router has the following pin-out:

| Pin # | RS-232 mode            |
|-------|------------------------|
| 1     | <i>Not in use</i>      |
| 2     | Tx                     |
| 3     | Rx                     |
| 4     | <i>Not in use</i>      |
| 5     | GND                    |
| 6     | GND                    |
| 7     | RTS                    |
| 8     | CTS                    |
| 9     | <i>Do Not Connect!</i> |

Note that if the standard RS-232 cable specification (DCE) is followed:

A cable with Male+Male or Female+Female connectors at the cable ends is used for Rx/Tx crossed connection, and

A cable with Male+Female connectors at the cable ends is used for a straight through connection.

#### 5.1.1 Maximum cable length (RS-232)

IEEE has specified the maximum cable length for an RS-232 connection to 15m. Longer distances can be installed depending on the environmental conditions of the installation site.

## **5.2 Ethernet connection**

The connections follow the standard set by the IEEE 802.3 100BaseTX specification. The cables that are to be applied should be CAT-5 / CAT-5E standard, or better. It is the responsibility of the installer / user to secure a proper installation of the Ethernet connection.

All Barco MatrixPRO-II routers and IP-based Control Panels are connected together through an Ethernet Switch.

A Barco MatrixPRO-II device has only one physical Ethernet connection. If redundant control is required, this limitation has to be solved by the control system.

## 6 Control Panel operation

### 6.1 Button description

#### A/V Toggle

The A/V Toggle button enables/disables audio and video on a specified address. The address can either be read from the dip switches, or be fixed. The button toggles between three states.

If the button is pressed for more than 1 second, it will go into a fourth state where both audio and video are disabled.

In this state the button will be dimmed. If the button is pressed for more than 1 second again, it will enable both audio and video if present.

| Button Color | Video Enabled | Audio Enabled |
|--------------|---------------|---------------|
| Yellow       | Yes           | Yes           |
| Green        | Yes           | No            |
| Red          | No            | Yes           |
| Dimmed       | No            | No            |

If neither audio nor video is present, it will be marked as disabled and the toggle state will not be used.

Toggle status changes will be stored in flash and used when the panel is powered up later.

When a panel is powered on it will search for connected routers. If no routers are found the A/V Toggle button will be disabled (no light in the button).

*This can happen if the panel is powered up before any routers are connected or if there is something wrong with the cabling.*

To re-enable the A/V Toggle do the following:

1. Activate the *Panel Enable* button (Green light).
2. Push & Hold the A/V Toggle-button for 2 seconds.

The A/V Toggle-button should now be activated and the light turned on.

#### Panel Enable

If a Panel Enable button is present, the panel will start up not enabled. In this state the button will be red and all the other buttons will be disabled. When pressing the button the panel will be enabled and the color will change to green. A status request will also be sent to get information on active levels.

If no Panel Enable button is present, the panel will start up enabled.

**Take on/off**

The Take on/off button enables or disables the Take button. If no take button is defined, Take on/off is always off. On first start-up the take button is enabled. Later it will read the last status from the flash memory.

**Take**

The Take buttons LED is normally off. If the Take on/off button is set to "on", no commands will be sent from the panel until the Take button is pressed. The last selected buttons and the take button will blink, until the Take button is pressed and the command is sent from the panel.

**Output**

An Output button is used for selecting an output. Selecting an output activates it, so that it is switched to the next input that is selected.

**Input**

An Input button switches the active output to the selected input. If the Take button is enabled, the switch will not be executed until the Take button is pressed.

When switching using the Input button, all enabled audio- and video-levels will be switched from the selected input to the active output.

**Environmental Specifications**

1. The equipment will meet the guaranteed performance specification under the following environmental conditions:
  - Operating room temperature            0°C to 45°C  
range:
  - Operating relative humidity range:   <95% (non-condensing)
  
2. The equipment will operate without damage under the following environmental conditions:
  - Temperature range:                    -10°C to 55°C
  - Relative humidity range:              <95% (non-condensing)



## Appendix A Materials declaration and recycling information

### A.1 Materials declaration

For product sold into China after 1st March 2007, we comply with the "Administrative Measure on the Control of Pollution by Electronic Information Products". In the first stage of this legislation, content of six hazardous materials has to be declared. The table below shows the required information.

| 組成名稱<br>Part Name   | Toxic or hazardous substances and elements |                   |                   |                                     |  |  |
|---|--|-------------------|-------------------|-------------------------------------|--|--|
|   | 鉛<br>Lead (Pb)                             | 汞<br>Mercury (Hg) | 鎘<br>Cadmium (Cd) | 六价铬<br>Hexavalent Chromium (Cr(VI)) | 多溴联苯<br>Polybrominated biphenyls (PBB) | 多溴二苯醚<br>Polybrominated diphenyl ethers (PBDE) |
| All products referred to in Chapter 1.1   | 0  | 0                 | 0                 | 0                                   | 0                                      | 0  |
| SL-PWR-40 / SL-PWR-90   | 0  | 0                 | 0                 | 0                                   | 0                                      | 0  |
| <p>O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.</p> <p>X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.</p> |  |                   |                   |                                     |  |  |

Parts without any of the above mentioned hazardous substances are indicated by the product marking:



## A.2 Recycling information

Please contact Barco's Customer Support for assistance with recycling if this site does not show the information you require.

Where it is not possible to return the product to Barco or its agents for recycling, the following general information may be of assistance:

- Before attempting disassembly, ensure the product is completely disconnected from power and signal connections.
- All major parts are marked or labeled to show their material content.
- Depending on the date of manufacture, this product may contain lead in solder.
- Some circuit boards may contain battery-backed memory devices.

**EC Declarations of Conformity**

|   |   |
|---|---|
| <b>DESCRIPTION</b>  | 3G/HD/SD-SDI Video Routers in the Barco MatrixPRO-II series |
| <b>DIRECTIVES this equipment complies with</b>                                      | LVD 73/23/EEC<br>EMC 2004/108/EEC                           |
| <b>HARMONISED STANDARDS applied in order to verify compliance with Directive(s)</b> | EN 55103-1:1996<br>EN 55103-2:1996                          |